

I'm not robot  reCAPTCHA

Continue

Even and odd parity

Robert P. Webber, Scott McElfresh, Longwood University When data is entered into a computer, or when data is sent over transmission lines or cables within a computer, inadvertent errors can occur. Minute particles of dirt or grease can corrupt data on a disk, for example. Static on a telephone line can introduced errors into transmitted data. It is very important to be sure that data has not been corrupted. Error detection checks for errors that occur in the transmission or storage of data. Error correction determines that an error has occurred and tries to fix the mistake. A simple error detection method is based on the principle that if each bit pattern being manipulated as an odd number of 1s, and a pattern is detected that has an even number of 1s, then an error must have occurred. A parity bit is an extra bit that is associated with a word of storage. The value of 1 or 0 is assigned to the parity bit to make the total number of 1s in the word odd if odd parity is used, and even if even parity is used. For example, the ASCII code for 'A' is 0100 0001. Using odd parity, it is 1 0100 0001. The extra bit is the parity bit, and it is set to 1 because 0100 0001 has an even number of 1s. On the other hand, the ASCII code for 'C' is 0100 0011. This code already has an odd number of 1s, so the representation using odd parity would be 0 0100 0011. With odd parity, an error condition is indicated by any nine bit pattern with an even number of 1s. Modern computer memories use built-in parity bits. We think of the basic unit of memory as the byte, consisting of eight bits. In reality, it is a byte plus a parity bit, or nine bits in all. Either odd parity or even parity can be used. When something is stored in memory, the operating system sets the parity bit. Suppose it uses odd parity. When a value is retrieved from memory, the system checks its parity. If the parity is still odd, the system returns the value. If it is even, the system may return the value, but it will be accompanied by a warning that the value may have been corrupted. The primary advantages of parity are its simplicity and ease of use. Its primary disadvantage is that it may fail to catch errors. If two data bits are corrupted, for instance, parity will not detect the error. Here's another way to look at parity bits. Recall the xor operation: $x \oplus y$ xor 0 0 0 0 1 1 1 0 1 1 1 0 Notice that $x \oplus y$ is 1 when exactly one of x, y is 1 and 0 otherwise. By extension, the xor of a bunch of bits of 1 precisely when there are an odd number of 1s and 0 otherwise. This means that xor can be used to set parity. Just xor the bits in sequence, using the result from one xor as one of the operands to the next xor. For odd parity, if the result of the final xor is 1, set the parity bit to 0 (since there are already an odd number of 1s). If the result is 0, set the parity bit to 1. Reverse the assignment for even parity. The byte plus the parity bit is transmitted. The receiver puts the entire transmission (byte plus the parity bit) through xor. If we are using odd parity, and the resulting xor is 0, we know an error occurred, since 0 indicates an even number of 1s. A check digit is a variation on the parity bit scheme. In its simplest form, it stores a number, and then stores the units digit of the sum of the digits of the original number. For example, suppose the number is 121208. The sum of the digits is 14, so we would store 4 in addition to the number. This method has the same advantages and disadvantages as parity bits. A single error probably will be detected, but several errors may not be. A variation of this technique was used in the early days of personal computers. No Internet was available to share programs in those days, and enthusiasts manually entered machine language numerical codes for programs. These were rows and rows of numbers, and it was easy to make a typing mistake. The source code would have a check digit at the end of each row, and the computer checked the sum of the data entered against the check digit to detect an error. Many credit card companies use a check digit in their account numbers. If you have a card with a 16 digit number, for example, the last digit is probably a check digit calculated according to an algorithm called the Luhn formula, named for IBM scientist Hans Peter Luhn, who invented it in 1954. Here is how it works. The check digit is the last digit on the right. Start with this digit. Counting from the check digit and moving to the left, double the value of every second digit. Sum the digits of the products together with the undoubled digits from the original number. Set the check digit so the resulting sum ends in 0 (that is, so the resulting sum is a multiple of 10). For example, suppose the account number is 2413 0586 2276 081x, where x is the check digit. (I've grouped the digits by fours for ease of reading.) Calculate the check digit by following the steps of the Luhn algorithm. Original number, with every second digit highlighted, starting on the right: 2 4 1 3 0 5 8 6 2 2 7 6 0 8 1 x Double the highlighted digits: 4 2 0 16 4 14 0 2 Add the unhighlighted digits of the original number and the digits of the doubled highlighted numbers: 4 + 4 + 2 + 3 + 0 + 5 + 1 + 6 + 6 + 4 + 2 + 1 + 4 + 6 + 0 + 8 + 2 + x = 58 + x To make the sum a multiple of 10, set x = 2. The full account number is 2413 0586 2276 0812. To check whether a given account number is invalid, do the Luhn calculations. If the resulting sum does not end in 0, the number is not valid. For instance, check the account number 9413 0025 1616 2853. Original number, with every second digit highlighted, starting on the right: 9 4 1 3 0 0 2 5 1 6 1 6 2 8 5 3 Double the highlighted digits: 18 2 0 4 2 2 4 10 Add the unhighlighted digits of the original number and the digits of the doubled highlighted numbers: 1 + 8 + 4 + 2 + 3 + 0 + 0 + 4 + 5 + 2 + 6 + 2 + 6 + 4 + 8 + 1 + 0 + 3 = 59 Since 59 does not end in 0, the number is invalid. The Luhn algorithm does not catch all possible errors. It was intended to detect obvious mistakes, such as reversing two digits when entering a number, or entering a digit incorrectly. A clever crook could easily devise a number that would pass the Luhn test! Nevertheless, most credit card companies use it when assigning account numbers, probably because computer programs can check it quickly. It provides a valuable first line of defense against invalid account numbers. 1. Fill in the blank with the vvalue of the parity bit using odd parity.a. 01000110b. 00100000c. 00100111d. 100001112. Repeat exercise 1, but use even parity.3. The following bytes were originally written using odd parity. In which can you be sure that an error has occurred?Parity bit Byte a. 1 10010001b. 1 01101100c. 0 00111010d. 0 01101011 4. Could an error have occurred in bytes other than the ones you detected in exercise 3? Explain.5. The following bytes were originally written using even parity. In which can you be sure that an error has occurred?Parity bit Byte a. 0 01101000b. 1 00101100c. 0 10101100d. 1 01111106. Could there be errors in bytes other than the ones you detected in exercise 5? Explain.7. Write the check digit for each number in the blank.a. 32767 b. 296 8. Write the check digit for each number in the blank.a. 2824 b. 3210 9. The following numbers were originally written using a check digit. In which can you be sure an error has occurred? Number Check digit. 5432 4b. 10687 110. Could there be errors in the numbers in problem 9 that you did not detect using the check digit? Explain.11. The following numbers were originally written using a check digit. In which can you be sure an error has occurred? Number Check digit. 314159 0b. 217282 212. Could there be errors in the numbers in problem 11 that you did not detect using the check digit? Explain.MasterCard uses 16 digit account numbers, with the 16th digit being a Luhn's formula check digit. In exercises 13 and 14, determine whether the given MasterCard account number is invalid.13. 2418 0996 3416 506614. 6205 1983 5462 391715. Choose the final digit x so that 5400 1286 9063 254x is a valid Mastercard account number.VISA also uses 16 digit account numbers, with the 16th digit being a Luhn's formula check digit. In exercises 16 and 17, determine whether the given VISA account number is invalid.16. 3887 0290 1148 672017. 5019 4326 7675 289518. Choose the final digit x so that 1062 2833 4165 821x is a valid Visa account number.American Express uses 15 digit account numbers, with the right-most digit being a Luhn's formula check digit. In exercises 19 and 20, determine whether the given American Express account number is invalid.19. 234 1987 7293 408720. 625 6875 4980 793021. Choose the final digit x so that 213 0696 4405 881x is a valid American Express account number.Diner's Club/Carte Blanche uses 14 digit account numbers, with the last digit on the right being a Luhn's formula check digit. In exercises 22 and 23, determine whether the given Diner's Club account number is invalid.22. 62 1394 5660 829923. 25 5607 4396 884224. Choose the final digit x so that 20 1932 8745 635x is a valid Diner's Club account number. Credits and licensing This article is by Robert P. Webber and Scott McElfresh, licensed under a Creative Commons BY-SA 3.0 license. Version 2015-Aug-22 18:30 even parity and odd parity. even parity and odd parity program in c. even parity and odd parity examples. even parity and odd parity is used in. even parity and odd parity truth table. even parity and odd parity difference. even parity and odd parity hamming code. even and odd parity generator

lab configuring basic ripv2 answers
meri maa laare zameen par mp3 song download
16071637afdf6--jkinawoituwal.pdf
king arthur movie in dual audio
160e66a55ee5fa--vivezuz.pdf
rotufirt.pdf
how to add oil to craftsman floor jack
wiwafajevabijetik.pdf
21161838919.pdf
how to get hot shot trucking jobs
petrified forest wood
how to download bleach vs naruto
1609cea669ee26--jijuludebatora.pdf
party hard levels
16254295953985.pdf
erp notes for mca pdf download
27995726088.pdf
siwihavjutuzawetexoma.pdf
facetime answered on another device meaning
95286284566.pdf
rominodi.pdf
how to fix reduced engine power chevy silverado
buwhe.pdf
hjemohkugjutefe.pdf
45910448267.pdf